



# SQ-Panel

Air Quality

**Getting Started for Commissioning  
Devices**

**Getting Started**

Thank you for choosing our air quality sensor!

To get started, you'll need a smartphone running Android 9.0 or higher or an Apple iPhone.

*Make sure your smartphone and the connector are on the same local network during installation.*

## 1. Install the Carenuty Home App

- Open the Google Play Store or Apple App Store.
- Search for "Carenuty Home" and install the app.
- Open the app and create your personal account.

## 2. Activate Your Account

You'll receive an activation email.

Open the email and click the activation link to confirm your account.



## 3. Set Up the Connector (Gateway)

- Connect the connector to your home internet router (e.g., Fritzbox) using a network cable. *Note: The red network cable is not included.*
- Use the green micro-USB cable (included) to power the connector.
- The LED next to the network cable will flash yellow. Wait while data exchange completes.

- Follow the instructions in the Carenuity Home app.

#### **4. Add Your Home Location**

In the app, tap "Add another location" and enter a name for your home.

#### **5. Add the Connector (Gateway)**

- Select "Add Gateway".
- After scanning for available gateways, choose your connector from the list.

*If no connector appears after selecting "Select Gateway", please contact our support team: +49 89 – 1222469 – 40*

Important note:

Your smartphone must be connected to the same Wi-Fi network as the connector. This means your phone should display the same Wi-Fi name (e.g., your Fritzbox Wi-Fi) that your connector is connected to via the Ethernet cable.

This is normally not an issue at home.

In office environments, however, ensure your phone is connected to the internal Wi-Fi, not the guest Wi-Fi, otherwise the connector may not be detected.

#### **6. Register the Carenuity Gateway**

Execute "Register Carenuity Gateway" to complete the registration.

#### **7. Name Your Gateway and Add Your First Room**

Give your connector a name and create your first room where your display device will later be placed.

#### **8. Open Your Location**

Tap the tab showing the name of your location to enter it.

#### **9. Add a New Device**

Swipe from bottom to top and select "Add New Device".

## 10. Set Up the Display Device (SQ-Panel)

- Plug in the display device using a USB Type-C cable (not included). o A QR code will appear directly on the display (SQ-Panel).
- Scan this QR code using the built-in scanner in the Carenuity Home app.

Note: The display device can be placed at very long distances, well beyond normal Wi-Fi range.

## 11. Assign a Name and Room for the Display Device

Choose a name and select the room where this device belongs.

### Device Setup Complete!

Your display device is now connected, and the air quality data is visible on the screen. You can also access your measurements securely at [Carenuity.com](https://Carenuity.com) using your login details.

The SQ-Panel includes explanations for readings such as: ppm, TVOC, kPa... and more, so you always know what the values mean.

## Navigator Overview

Inside the Navigator you can:

- Configure your rooms and Set threshold values under Carenuity Gateways.
- Add more display devices under Carenuity Devices.

To add another device:

- Open Carenuity Devices Tap the green plus (+) symbol to activate the QR scanner.
- Scan the QR code shown on the new display device.